



# **OWNER'S MANUAL**

**C7-2K**

**C7-4K**

**C7-2000.4**

**C7-2200.5**

## DIGITAL MONOBLOCK FEATURES

- Digital Class-D Strapable Mono Block Amplifier
- Dual MOS-FET PWM Power Supply
- Stable Into 1 Ohm Mono Load
- 24 dB/Octave - Variable Low Pass Filter
- 24 dB/Octave - Variable Subsonic Filter
- 180 Degree Variable Phase Shift
- 9 dB/Octave - Variable Bass Boost
- 4 Way Protection Circuit  
( Thermal, Voltage, Speaker Short and DC Offset )
- C7 Amplifiers Operating Voltage Range : 9V - 16V
- 0 Awg Power & Ground Inputs
- Subwoofer Level Controller Included

## DIGITAL MONOBLOCK SPECIFICATIONS

Rated Power Output ( @ 12.5V )	<b>C7-2K</b>	<b>C7-4K</b>
- RMS Power, 1 Ohm Mono -----	2,000W x 1CH	4,000W x 1CH
- RMS Power, 2 Ohm Mono -----	1,200W x 1CH	2,200W x 1CH
- RMS Power, 4 Ohm Mono -----	800W x 1CH	1,200W x 1CH
Low Pass Frequency Crossover -----	35Hz ~ 250Hz	35Hz ~ 250Hz
Subsonic Filter -----	10Hz ~ 50Hz	10Hz ~ 50Hz
Phase Shift Control -----	0 ~ 180 Degree	0 ~ 180 Degree
Frequency Response -----	15Hz ~ 250Hz ( +/- 1dB )	15Hz ~ 250Hz ( +/- 1dB )
Input Sensitivity -----	0.2V ~ 6V ( +/- 5% )	0.2V ~ 6V ( +/- 5% )
Signal/Noise Ratio -----	90dB	90dB
T.H.D @ 4 Ohm -----	< 0.1%	< 0.1%
Efficiency @ 4 Ohm -----	90%	90%
Recommended Fuse Rating -----	200A ( External Type Fuse )	400A ( External Type Fuse )
Operationg Voltage -----	9V ~ 16V	9V ~ 16V
Dimensions -----	18.90 (L ) Inches	23.25 (L ) Inches
9.29(W ) x 2.48(H )		

All features are subject to change in the continuing effort to improve the products without notice.

## DIGITAL 4 CHANNEL FULL RANGE FEATURES

- Digital 4 Channel Full Range Amplifier
- Dual MOS-FET PWM Power Supply
- Stable Into 2 Ohm Stereo Load
- 12 dB/Octave - Variable Low Pass Filter
- 12 dB/Octave - Variable High Pass Filter
- Clipping Indicators For All Channels
- 4 Way Protection Circuit  
( Thermal, Voltage, Speaker Short and DC Offset )
- C7 Amplifiers Operating Voltage Range : 9V - 16V
- 0 Awg Power & Ground Terminal
- Bandpass Capable
- Subwoofer Level Controller Included

## DIGITAL 4 CHANNEL FULL RANGE SPECIFICATIONS

Rated Power Output ( @ 14.4V )

### C7-2000.4

- RMS Power, 4 Ohm Bridged -----	1,000W x 2CH
- RMS Power, 2 Ohm Stereo -----	500W x 4CH
- RMS Power, 4 Ohm Stereo -----	300W x 4CH
High Pass Frequency Crossover -----	20Hz ~ 4KHz
Low Pass Frequency Crossover -----	40Hz ~ 4KHz
Frequency Response -----	10Hz ~ 35KHz ( +/- 1dB )
Input Sensitivity -----	0.2V ~ 6V ( +/- 5% )
Signal/Noise Ratio -----	90dB
T.H.D @ 4 Ohm -----	< 0.1%
Efficiency @ 4 Ohm -----	86%
Recommended Fuse Rating -----	150A ( External Type Fuse )
Operating Voltage -----	9V ~ 16V
Dimensions -----	14.60 ( L ) Inches
9.29(W ) x 2.48(H )	

All features are subject to change in the continuing effort to improve the products without notice.

## DIGITAL 5 CHANNEL FEATURES

- 4 Channel Full Range Digital Circuit & Stable into 2 Ohm Stereo Load
- CH5 is Digital Monoblock Circuit & Stable into 1 Ohm Load
- Dual MOS-FET PWM Power Supply
- Stable into 2 Ohm Mono Load
- 12 dB/oct, Variable Low Pass Filter
- 12 dB/oct, Variable High Pass Filter
- 12dB/oct, Variable Subsonic Filter
- Band Pass Capable for CH3 & CH4
- Clipping Indicators for All Channels
- C7 Amplifiers Operating Voltage Range : 9V - 16V
- 0 Awg Power & Ground Terminal
- 4 Way Protection Circuit  
(Thermal, Voltage, Speaker short and DC)
- Subwoofer Level Controller Included

## DIGITAL 5 CHANNEL SPECIFICATIONS


Rated Power Output ( @ 14.4V )

### C7-2200.5

- RMS Power, 4 Ohm Bridged	-----	360W x 2CH for CH1 - CH4
- RMS Power, 10hm Mono	-----	1,500W x 1 CH for CH5
- RMS Power, 2 Ohm Stereo	-----	180W x 4CH + 1000W x 1CH
- RMS Power, 4 Ohm Stereo	-----	125W x 4CH + 600W x 1CH
High Pass Frequency Crossover	-----	20Hz ~ 5KHz for CH1 - CH4
Low Pass Frequency Crossover	-----	50Hz ~ 5KHz for CH3 & CH4, 35Hz ~ 250Hz for CH5
Subsonic Frequency Crossover	-----	10Hz ~ 50Hz
Frequency Response	-----	10Hz ~ 25KHz ( +/- 1dB ) for CH1 - CH4 & 10Hz ~ 250Hz ( +/- 1dB ) for CH5
Input Sensitivity	-----	0.2V ~ 6V ( +/- 5% )
Signal/Noise Ratio	-----	90dB
T.H.D @ 4 Ohm	-----	< 0.1%
Efficiency @ 4 Ohm	-----	85%
Recommended Fuse Rating	-----	200A ( External Type Fuse )
Operating Voltage	-----	9V ~ 16V
Dimensions	-----	18.90 (L) Inches
9.29(W) x 2.48(H)		

All features are subject to change in the continuing effort to improve the products without notice.

# POWER CONNECTIONS



## ⚠ CAUTION

C7-2K, C7-4K, C7-200.4 & C7-2200.5 are not supplied with an internal fuse. Make sure you install a in-line fuse holder from the positive (+) terminal of the battery.  
C7-2K : 200A, C7-4K : 400A, C7-200.4 : 150A, C7-2200.5 : 200A

### +12V POWER

Connect the + 12V terminal of the amplifier to the positive (+) terminal of the battery using the same diameter cable as the ground cable, making sure you install a in-line fuse holder, approximately 300 or 400 mm from the positive (+) terminal of the battery.

### GROUND

Disconnect the battery and connect the GND (Ground) terminal to the car's chassis.

Keep this cable as short as possible ( not longer than 20 inches or less )

Making sure that the connection with the chassis is rust free and clear of paint or grime.


### REMOTE

Connect the REM terminal of the amplifier to the power antenna terminal in the car ignition switch using 12 or 14 awg electrical wire.


# STRAPPED INPUT & SPEAKER CONNECTION

## MASTER & SLAVE RCA CONNECTION

### MASTER UNIT



### SLAVE UNIT




In a strapped mode configuration, the master amplifier has total control over the slave amplifier. When using a strapped mode to operate a subwoofer, the positive terminal of the subwoofer's voice coil must be connected to the positive terminal of the master amplifier and the negative terminal of the subwoofer's voice coil must be connected to the positive terminal of the slave amplifier. When wiring two amplifiers to a single subwoofer, please make sure power handling capabilities will not be exceeded.

### **!** CAUTION

C7-2K & C7-4K minimum working impedance is 1 ohm for a single amplifier or 2 ohm for two amplifiers in a strapped configuration. Impedance lower than 1 ohm or 2 ohm strapped can damage the amplifiers.


# STRAPPED INPUT & SPEAKER CONNECION



## ⚠ CAUTION


C7-2K & C7-4K Operation Voltage : 9V to 16V  
C7-2K & C7-4K Strapped Minimum Impedance is 2 Ohms

## C7-2000.4 INPUT CONNECTION



## C7-2000.4 SPEAKER CONNECTIONS

### C7-2000.4 SPEAKER 4 WAY CONNECTION




### ⚠ CAUTION

C7-2000.4 Operation Voltage : 9V to 16V

C7-2000.4 Minimum Impedance is 2 Ohm Stereo or 4 Ohm Mono


C7-2000.4 Fuse Rating is 150A

### C7-2000.4 SPEAKER 3 WAY CONNECTION






# C7-2200.5 INPUT CONNECTION



# C7-2200.5 SPEAKER CONNECTIONS

## C7-2200.5 SPEAKER 3 WAYS CONNECTION




### ⚠ Caution !!

C7-2200.5 operation voltage : 9V to 16V

C7-2200.5 minimum impedance is 2ohm stereo or 4ohm mono for CH1 ~ CH4 and 1ohm mono for CH5

C7-2200.5 fuse rate is 200A

# C7-2200.5 SPEAKER 5 WAYS CONNECTION



## TROUBLE SHOOTING

C7-2K, C7-4K, C7-2000.4 & C7-2200.5 amplifiers have protection features to prevent any damages from misuse or faulty conditions. If C7-2K, C7-4K, C7-2000.4 & C7-2200.5 amplifiers sense excessive heat, short circuited speaker, DC offset or voltage below 9 volts or over 16 volts the protection indicator will light and the system will be turned off.

In order to check the problem, you should turn all levels down and all power off and carefully check the installation for wiring mistakes or short. If C7-2K, C7-4K, C7-2000.4 & C7-2200.5 shut down due to excessive heat, they will remain in thermal protection until amplifier reaches normal operation temperature.

**Before removing your amplifiers, refer to the list below and follow the suggested procedures.**

### NO OUTPUT

@ Check remote turn-on voltage at amplifier and headunit, when remote turn-on voltage is low or no turn-on voltage, there is no sound.

@ Check fuses at the battery side or external fuses and all wire connections

@ Check RCA Input is properly connected.

### AMPLIFIER SHUT DOWN ( PROTECTION )

@ Please check POWER, GND and REMOTE wire connection and other wires properly connected.

@ If the amplifier sees over 4 volts DC offset the amplifier will go into protect mode. Please check whether amplifier works after removing RCA-Input. If the amplifier works, then check DC offset by checking RCA-Input when DC offset is over 4 volts at input, check by replacing the source unit.

@ Amplifier goes into the thermal protection when amplifier is over-heated. Amplifier will turn back on after it cools down. Please install amplifier in a better ventilated area.

@ C7-2K & C7-4K have a minimum working impedance of 1ohm as single unit. Strapped connection is 2ohm.

C7-2000.4 has a minimum working impedance of 2ohm stereo or 4ohm bridged.

C7-2200.5 has a minimum working impedance of 2ohm stereo or 4ohm bridged for H1 ~ CH4 and 1ohm for CH5.

@ C7-2K, C7-4K, C7-2000.4 & C7-2200.5 voltage protection will activate when voltage goes below 9 volts or over 16 volts.

@ Make sure Chassis and Remote use same GROUND.

### DISTORTION & NOISE

@ Please re-adjust amplifier input level which is printed on endplate.


@ Make sure good ground contact of amplifier or source unit.

@ Use sufficiently shielded RCA interconnects and good RCA routing.

@ Check all ground connections of all other audio equipment.

### POOR BASS RESPONSE

@ Check speaker wiring and reverse polarity.



**STILL  
LOUDER!**

756 Port America Place. Suite 100 Grapevine, TX. 76051

PH: (972) 570-0800 FX: (972) 570-2200

[www.crossfirecaraudio.com](http://www.crossfirecaraudio.com)